

CARING FOR YOU AND YOUR TOYOTA



ALWAYS A
BETTER WAY

At Toyota, our number one priority is to produce the safest and most reliable cars we can. Our Toyota driver's card is designed to give you a quick and easy guide to maximise enjoyment from your Toyota, with simple to follow instructions that will help you maintain a safe and reliable car for many years.

SEAT POSITIONING



- Depress pedals fully keeping hips level with thighs.
 - Seat back at 100° - 110°.
 - Hands on the wheel at 10-2.
- Arms slightly bent and wrists straight.
- Drive with both hands to maintain control.

Pay attention to your driving posture and take regular breaks.

TYRE MAINTENANCE



- Check tyre for cracks & damage.
- Minimum legal limit is 1.6mm.
- Use wear bars moulded between the grooves as a reference point.

Turn wheel to inspect the inner shoulder of tyre.

OIL MAINTENANCE



- Locate dipstick as shown.
- Clean oil from end of dipstick.
 - Replace dipstick.
- Remove and read oil level between dipstick markers.

Oil should be transparent and clean when checked, otherwise renew.

TYRE INFLATION



- Locate correct tyre pressure in owner's manual or on door pillar.
- Check tyre pressure with gauge.
- Add or remove air as required.

Incorrectly inflated tyres can lead to excessive wear to centre and outer edges. Poorly inflated pressures can cause steering to pull to one side.